

4150.0009

INSTALLATION INSTRUCTIONS FOR UNIVERSAL FEED - THRU CODE RA140

Select the area for installing the universal feed thru.

Before drilling chek you are not going to damage tubes, cables, etc that are inside the boat.

Drill 25 mm (1"), on fibreglass is suggested the use of an hole saw.

Seal by silicon around the hole

Drill three holes for the supplied screw and tighten down.

Follow the instructions on drawns 2 and 3 if use RA 140 for two cable:



www.glomex.it