


# COAXIAL LIGHTNING SURGE PROTECTOR

**SP1000** (TYPE:M-J/M-J)

**SP3000** (TYPE:N-J/N-J)

**SP3000P** (TYPE:N-J/N-P)



## Instruction Manual

To use the unit properly, read the instructions thoroughly before installing the unit. Keep the instructions at hand to refer to it if necessary.

### Caution

1. To avoid shock, do not touch the unit and a coaxial cable being connected to the unit after the thunder lightening starts.
2. To avoid damaging radio equipment from thunder lightening, disconnect a coaxial cable from the equipment and keep it away as possible from your reach, preferably outside, if the equipment is switched off for a long time.
3. To install the unit, be sure to provide stable foot step to avoid falling down or slipping off from a ladder,
4. To avoid injuring other people, do not drop the unit, parts, or tools.
5. To avoid falling,slipping,or injuring,do not install or inspect the unit under bad weather condition.
6. To avoid causing fire,shock,or injuring,do not connect ground the unit to a gas pipe or water pipe.

### Note

1. Do not share the ground line with other utility ground lines such as power line. It is recommended to separate the unit's ground line from ones in other systems to avoid malfunctioning the unit.
2. Though the unit is designed to work well to protect radio equipment from high surge voltage caused by the static electrocutions or thunder lightening, it cannot protect the equipment from high current and voltage caused by a thunder strike itself. To protect the equipment from the strike, install proper thunder conductor separately.

### Features

1. To achieve maximum safety, the unit employs builtin pressured gas tube surge arrester element to discharge and ground the surge current when it exceeds predetermined discharge voltage.

2. The unit starts discharging at predetermined voltage and stops discharging repeatedly as necessary. It is practically no need to replace the unit. And, if the unit is broken by chance, it is easily accessible to replace the unit without calling a service.
3. Coaxial structure of the unit allows the unit to have good RF performance, broad bandwidth, low insertion loss, and low VSWR.

### Installation


1. It is recommended to install the unit at the place where has easy access to the grounding point such as the place where a coaxial cable is fed into the building.(Fig 1)
2. Crimp or solder a copper wire, with 2.5 to 3.2mm diameter, to a grounding lug and connect the other end to buried earth ground. It is recommended to make the grounding line as short as possible.

### ★To make good surge grounding

take the following precautions in mind and refer to those books specialized in grounding, or consult with specialist.

- Make grounding resistance as low as possible.
- To make ground contact are as large as possible, use electrode such as copper plate as large as possible.
- When the antenna is installed on a tower high above the ground, ground the base section of the tower with thick wire (more than 30mm copper wire or more than 50mm cross sectional area aluminum wire). Then install the unit at right below the antenna and connect the unit's earth section to the tower to use the tower as effective grounding line.

Model Name	SP1000	SP3000	SP3000P
Frequency range	DC-1000MHz	DC-3000MHz	
Impedance		50Ω	
VSWR		Less than 1.2	
Insertion loss		Less than 0.3dB	
Max.power rating	400WPEP	200WPEP	400WPEP
DC breakdown voltage (100V/S)	350V±20%	230V±20%	350V±20%
Max.impulse breakdown voltage (1000/μS)	800V	650V	800V
Nominal impulse discharge current (8/20μS 10 times)		10kA	
Impulse life (10/ 1000 μS) 100A(times)		300 times	
DC holdover voltage		150V	
Insulation resistance		Over 10,000MΩ	
Connector	M-J/M-J	N-J/N-J	N-J/N-P
Outer dimensions(mm)	66Wx41Hx20D	78Wx41Hx20D	77Wx41Hx21D
Weight(Approx.)	80g	110g	110g



SP1000

SP3000

SP3000P

## 同軸避雷器（雷サージ・プロテクター）

**SP1000**  
**SP3000**  
**SP3000P**

M形接栓付(M-J/M-J)

N形接栓付(N-J/N-J)

N形接栓付(N-J/N-P)



### 取扱説明書

ご使用の前に、この取扱説明書をよくお読みの上、正しくお使い下さい。また、必要な時に読めるようこの取扱説明書は大切に保管下さい。

#### ⚠ 警告


- ①雷が鳴り出したら、本器やケーブル等から出来るだけ離れ、これらに触れる事はしないで下さい。落雷による感電死傷事故の原因になります。
- ②不安定な場所、高所等足場の悪い場所に設置工事をしないで下さい。落ちたり、滑ったりして、怪我の原因になります。
- ③本器の部品や工具類を高い所から落とさないで下さい。怪我や死傷事故の原因になります。
- ④設置や点検は、風雨、雷、雪などの天候の悪い日は、危険ですので作業をしないで下さい。落ちたり、滑ったりして、怪我や死傷事故の原因になります。
- ⑤ガス管や水道管等にアースしないで下さい。爆発や火災、感電、死傷事故の原因になります。

#### ⚠ 注意

- ①電力保安用のアース等と共にしないで下さい。また、他のアース回路となるべく隔離するようにして下さい。逆効果となるばかりでなく接続された各機器の故障や感電の原因になります。
- ②アンテナに落雷する事があります。無線機器や人身、家屋を保護する為、お使いにならない時や外出時には無線機から同軸ケーブルを外して屋外に出し、アースしておく事を、お奨め致します。
- ③本器は、誘導雷や静電気等の本器定格内のサージ電流等に対しては非常に効果的です。しかし、定格を超える直撃雷等による大電流には耐える事が出来ず、効果を失い破損します。直撃雷対策としては別に避雷針を設置して下さい。

#### ●特長

- ①本器は、同軸ケーブルの内外導体間に定格以上の電圧が生じると放電するガス封入式のサージ・アレスター素子 (GDT) を内蔵していますので、極めて安定性、安全性に優れています。
- ②サージ・アレスター素子は、定格電圧で放電、定格以下で復帰を定格回数まで繰り返し動作する事が出来ますので、通常の条件下では交換の必要は殆ど有りません。万一、サージ・アレスター素子が寿



SP1000

SP3000

SP3000P

命若しくは破損した場合には、容易に交換する事が出来る構造設計としておりますので極めて経済的です。

- ③本器は同軸管構造の採用と弊社独自のノウハウの投入により、極めて高周波特性が良く、また広帯域、低損失、低V.SWRと相反する耐サージ性能の向上との両立を実現した画期的な商品です。

#### ■設置方法

- ①本器は同軸ケーブルを屋内に引き込む直前や、接地し易い場所に取り付けてください。
- ②接地端子には2.5φ~3.2φの絶縁電線をかしめ、または半田付けしてから銅線の先端を大地に埋設したアースに接続して下さい。避雷用のアース線は絶縁電線管内に挿入敷設するか碍子等で転体から隔離した方がより安全性が高まります。また、この時、本器と大地の接続距離は出来るだけ短くして下さい。

☆避雷用のアースは次の点に留意し、確実に行って下さい。尚、詳細はアースに関する専門書を参照頂くか、専門の工事業者に御相談下さい。また弊社ホームページ(<http://www.diamond-ant.co.jp>)にもアースに関する情報が記載されておりますので御利用下さい。

- ・接地抵抗値は出来るだけ小さくして下さい。10Ω以下が理想です。(例10Ω × 1000A = 10000Vの対地電位の上昇となります)
- ・銅板を大地に埋設する等し、接地電極の表面積を広くして土壤との接触面積を大きくして下さい。
- ・地上高の高いアンテナ・タワー等を御使用の場合は、アンテナ・タワー やルーフタワー等の基部を出来るだけ太い線(断面積30mm<sup>2</sup>以上の銅線または50mm<sup>2</sup>以上のアルミ線)で接地すると共にタワー上のアンテナ直下に同軸避雷器を取り付け、避雷器のアースをタワーを通して接地すると効果的な避雷対策となります。

#### ■点検

サージ・アレスター素子の点検及び交換は、アースネジを取り外し、アレスター本体を傾けて取り出して下さい。また、取り付けは、指先で締め付けて下さい。アースネジは工具で締めないで下さい。サージ・アレスター素子が破損する恐れがあります。

型名	SP1000	SP3000	SP3000P
周波数範囲	DC~1000MHz	DC~3000MHz	
インピーダンス		50Ω	
V・SWR		1.2以下	
ロス		0.3dB以下	
高周波耐電力	400WPEP	200WPEP	400WPEP
直流放電開始電圧 (100V/S)	※1 350V±20%	230V±20%	350V±20%
インパルス放電開始電圧 (1000V/μs)最大値	※1 800V	650V	800V
インパルス放電電流耐量 (8/20μs 10回)		10kA	
インパルス放電寿命耐量 (10/1000μs 100A)		300回	
直流ホールドオーバー電圧	※1	150V	
絶縁抵抗(常温常湿)	※1	10GΩ以上	
コネクター	※1 M-J/M-J	N-J/N-J	N-J/N-P
外形寸法(mm)	※2 66WX41HX20D	78WX41HX20D	77WX41HX21D
質量	約80g	約110g	約110g

※1.アレスター素子単体の規格です。JIS C 5381-3-11(ISO/IEC ITU-T 準拠)

※2.コネクターを含む寸法です。

2008年5月 第1版 28K036-04d